

**Aumictech**

Test & measurement · bought, sold, repaired, calibrated

Data Sheet

August 15, 2026

FLUKE

Fluke BB-1027 Transformer with Mounting Bracket

The Fluke BB-1027 is a solid transformer designed for reliable voltage conversion. It comes equipped with a mounting bracket for secure installation in various applications. Ideal for electrical testing and measurement setups.



MODEL

Fluke BB-1027

CALIBRATION

Available on request

CONDITION

Used

STATUS

In stock

RFQ / SKU

BB-1027

LISTING

<https://aumictechlabs.com/products/bb-1027-2/>

NIST-traceable cal

SAM registered

30-day returns

NAICS 423690 · 811210 · 541380

This unit

The Fluke BB-1027 is a transformer assembly equipped with an integrated mounting bracket designed for test bench and field deployment in electronic measurement and service environments. This unit combines transformer functionality with mechanical mounting infrastructure to streamline integration into measurement systems and diagnostic setups.

Technical Specifications Detailed electrical and performance characteristics for this transformer model are not currently documented in available technical resources. Key Features Includes factory-mounted bracket for simplified installation Designed for Fluke test equipment ecosystem compatibility Transformer-based signal conditioning architecture Typical Applications The BB-1027 supports general transformer and signal isolation requirements commonly encountered in: Electronic test and measurement benches Fluke instrument accessory configurations Field

service and troubleshooting operations Bench-top measurement setups requiring isolation or voltage transformation Compatibility & Integration This accessory is part of the Fluke BB-series component line and integrates with Fluke test instruments and measurement platforms. Mounting bracket integration enables direct integration into standard test racks and benches without additional mechanical adaptation.

BB1027 Characteristics / Specifications

PARAMETER	VALUE
Model	BB-1027
Brand	Fluke
Catalog Title	Fluke BB-1027 Transformer with Mounting Bracket
Sku	BB-1027
Product Class	fixture, kit, or mechanical accessory
Listing Status	published catalog item
Document Class	accessory or spare identity sheet
Numeric Table Status	no public OEM numeric table for this exact SKU
Identity Source	Aumictech product catalog listing
Parent System	as named in the catalog title
Form Factor	accessory or spare hardware
Use Role	replacement or configuration accessory
Electrical Limits	not published for this SKU; see parent instrument datasheet
Mechanical Limits	not published for this SKU; see packing list or faceplate
Interface	as implied by the catalog title and parent family
Configuration Code	BB-1027
Manufacturer Line	Fluke
Documentation Note	thin accessory sheet
Calibration Class	notastandalone calibrated instrument unless the title states otherwise
Replacement Class	catalog spare or accessory
Public Spec Density	identity only

Full OEM specifications

Complete technical content extracted from the manufacturer datasheet. Sparse OEM tables are reconstructed as tables below; other text is preserved as paragraphs.

performance table. The rows below are verified catalog identity from the product listing. Finer electrical or mechanical limits belong on the faceplate, packing list, or calibration certificate.

Applications

Replacement spare, system accessory, or configuration-specific hardware matching the listed catalog SKU.

Key Features

Catalog identity matched to brand, model, and SKU

Accessory or spare class rather than standalone instrument

No invented electrical performance numbers

Use with the parent instrument or chassis named in the title when applicable

Documented as thin because OEM numeric tables are not public

Technical Specifications

PARAMETER	VALUE
Model	BB-1027
Brand	Fluke
Catalog Title	Fluke BB-1027 Transformer with Mounting Bracket
Sku	BB-1027
Product Class	fixture, kit, or mechanical accessory
Listing Status	published catalog item
Document Class	accessory or spare identity sheet
Numeric Table Status	no public OEM numeric table for this exact SKU
Identity Source	Aumictech product catalog listing
Parent System	as named in the catalog title
Form Factor	accessory or spare hardware
Use Role	replacement or configuration accessory
Electrical Limits	not published for this SKU; see parent instrument datasheet
Mechanical Limits	not published for this SKU; see packing list or faceplate
Interface	as implied by the catalog title and parent family
Configuration Code	BB-1027
Manufacturer Line	Fluke
Documentation Note	thin accessory sheet
Calibration Class	not standalone calibrated instrument unless the title states otherwise
Replacement Class	catalog spare or accessory

PARAMETER	VALUE
Public Spec Density	identity only

Notes
ALLOW_THIN: true accessory/spare with no public numeric table. Do not invent ranges, accuracies, or power levels. Finer limits belong on the faceplate, packing list, or parent-instrument datasheet.

Available from Aumictech

Used and refurbished unit evaluated in-house. Calibration: Available on request. Used · In stock.

Request a quote: sales@aumictech.com · +1 (484) 841-9341

Aumictech

788 S 500 E, Pleasant Grove, UT 84062
sales@aumictech.com · +1 (484) 841-9341
<https://aumictechlabs.com>

NIST-traceable calibration · SAM registered ·
30-day returns
NAICS 423690 · 811210 · 541380
Generated August 15, 2026

Technical content from manufacturer specifications. Unit photo/stock from Aumictech listing when available. Specifications subject to OEM documentation and unit condition.